



PHOTO CUBE® mini

 Charging Port

 Open here to replace cartridge





 Press 5 seconds to power on/off

 Photo Dispenser Slot


*compatible devices only



1 Download Photo Cube® Wireless App





2 Select "Direct-Cube-XXXX" to connect via Wi-Fi *

*Note: "XXXX" is a combination of A - Z, 0 - 9, alphanumeric characters

CHOOSE A NETWORK... 

DIRECT-Cube-XXXX  

Wi-Fi  ON

DIRECT-Cube-XXXX
Secured with WPA2 (WPS available) 

NFC Connection (for compatible Android devices ONLY) :

- Enable NFC on your smart device
- Tap smart device on top of printer to open the app

3 Open the app, and make sure you are connected!

 Connected

Be creative!
Print and share your photos instantly!



IPWF-P01-VP_QSG_14-1125
All trademarks are the property of their respective owners.
11252014 Specifications subject to change without prior notice